

IMPORTANT SAFEGUARDS

1. Read all instructions
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against electrical shock do not immerse Cord , plugs , or (state specific part or parts in question)
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination , repair , or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
8. Do not use outdoors (this item may be omitted if the product is specifically intended for outdoor use).
9. Do not let cord hang over edge of table or counter , or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner , or in a heated oven.
11. Extreme caution must be used when moving an appliance hot oil or other hot liquids.
12. Always attach plug to appliance first , then plug cord into the wall outlet. To disconnect ,turn any control to "Off " , then remove plug from wall outlet.
13. Do not use appliance for other than intended use.
14. Avoid sudden temperature changes , such as adding refrigerated into a heated pot.

SAVE THESE INSTRUCTIONS

USAGES

1. Evenly space the herb medicine. Leaves that are smaller place on the bottom; leaves that are larger place on the top.
2. Pour the amount of water that was specified by the Chinese medicine doctor and cover the pot.
(Note: the water must be at least exceed the entire stainless steel located on the bottom of the pot)
3. Before boiling, soak the herbal medicine in water for around 30 minutes. Then switch on the herbal medicine cooker by plugging in the power cord. (the red light and green will turn on at the same time)
4. During the decoction, no need to stir the medicine. Upon completion, the herbal medicine cooker will automatically switch to keep warm mode. (the red light will turn off and the green light still on)
5. During the keep warm function, the power light (red light) will automatically switch on in every 30 minutes for a second, then it will switch to the off position. (this is normal)
6. Do not leave the keep warm mode on for more than 2 hours. The herbal medicine may absorb the herbal juices and decrease medicinal effect.
7. Because some herbs tend to be more absorbent, it is normal for the resulting herbal medicine might only turn out to be 7/10- 1 bowl.
8. Unplug the power supply and pour out the herbal juices and materials immediately. Clean the herbal medicine cooker with water. (Or for easier cleaning, pour water into the pot and let it soak for about 10 minutes before washing) Please use a wet cloth or sponge to clean. Do not use a hard or rough material to clean the stainless steel.
9. Wipe the inner part dry, and store it carefully.

REMARKS

After the completion of the decoction, the red light will turn off and only the green light on to notify you that it is currently in heat preservation mode. If no herbal juices come out when pouring, please examine by the following steps:

1. Without the herbal medicine, just add water until it exceeds the stainless steel thermal.
2. Turn on the herbal medicine cooker by plugging in the power cord for starting to cook.
3. If the water level is below the thermal conductor, the herbal medicine cooker's light will automatically switch from red to green (it is currently in keep warm mode). This means the cooker is functioning properly, there is nothing wrong with it.



MADE IN TAIWAN

NARITA®

USER INSTRUCTION MANUAL

NAME OF THE VARIOUS PARTS

